

Snom M9R Guide




Navigation key

In idle mode, press top/bottom/right/left edge (depicted in this guide by $\uparrow/\downarrow/\rightarrow/\leftarrow$, respectively) or the button in the center (○) to open the following menus or functions:

- Main menu
- ↓ Directory
- ← Intercom
- Settings menu
- ↑ Preferences menu


In other contexts press \uparrow or \downarrow to navigate in menus and lists.

DISPLAY LAYOUT, IDLE SCREEN



PHONE MENUS

1. Press center of navigation key to open top-level menu.





2. Press top/bottom/right/left edge of navigation key (indicated in this guide by \uparrow \downarrow \rightarrow \leftarrow) to navigate on display.
3. Press function key "OK" to open submenu/function. Press function key "Cancel" to return to idle screen.

DIRECTORY

Use ↑↓ to select existing entry or <New Item>.

New item: Follow the prompts to enter name and number and select ringer. Press OK.

Press  (green phone key) to dial number, press  to leave directory.

PHONE OPERATION

Make and answer calls

Make a call: Enter number > press OK or 

Answer a call: Press 

Terminate call: Press 

Redial

Press  > select number > press  or "OK"

Call forwarding

Preferences > Call forwarding > enter PIN > OK > select identity > select event (always, busy, timeout) > select SIP address > enter target phone number > press OK > on prompt press Yes to reboot phone

Turn off call forwarding: Preferences > Call forwarding > enter PIN > OK > select identity > select event "never"

Hold and resume

Hold call: Press Options > Hold

Unhold call: Press Options > Unhold

Transfer call

With call on line, press Options > Transfer > enter number > press OK